




LC FLEX ANGLE BOOT




LC 90° ANGLE BOOT




LC 50° ANGLE BOOT




LC RIGHT ANGLE CLIP



SC FLEX ANGLE BOOT




MPO FLEX ANGLE BOOT




The FLEX ANGLE BOOT SERIES is RoHS, Reach SVHC and UL 94 V-0 compliant.


FC FLEX ANGLE BOOT




ST FLEX ANGLE BOOT



DIN FLEX ANGLE BOOT




D4 FLEX ANGLE BOOT




SENKO®
Advanced Components

Bend any angle or direction from straight to 90°



FLEX-BOOTS



SENKO ADVANCED COMPONENTS, INC.

America
USA EAST 1-888-32-SENKO
USA WEST 1-858-623-3300
TEXAS 1-972-661-9080
Sales-Americas@senko.com

South America
BRAZIL +55-21-3736-7065
Sales-Brazil@senko.com

Asia
HONG KONG +852-2121-0516
SHANGHAI +86-21-5830-4513
SHENZHEN +86-755-2533-4893
Sales-Asia@senko.com

Europe
FRANCE +44 7939364565
Salesfrance@senko.com
GERMANY +49(0)15117683072
Sales-Germany@senko.com
ITALY +39 338 8919089
Sales-Italy@senko.com
POLAND +44 (0) 7796444488
Sales-Europe@senko.com

SPAIN & PORTUGAL +34 678042829
Sales-Iberia@senko.com
UK +44 (0) 1256 700880
Sales-UK@senko.com
OTHER +44(0) 1256 700880
Sales-Europe@senko.com

Asia Pacific
AUSTRALIA +61 (0) 3 9755-7922
Sales-Asia-Pacific@senko.com

Middle East North Africa
DUBAI +971 4 8865160
Sales-MENA@senko.com

Japan
TOKYO +81 (0) 3 5825-0911
Sales-Japan@senko.com

CALL 1-888-32-SENKO

www.senko.com

FLEX ANGLE BOOT

The Flex-Angle boot is designed to bend any angle or direction from straight to 90°.

SENKO's Flex-Angled boot is solving the congestion problems that naturally occur when hundreds of fibers terminate at one small patch panel. The Flex angle boot is designed to perfectly dress the fibers. Installers and technicians can bend the boot to any angle desired after connector insertion for proper cable management.

FEATURES


- Flexible in any direction
- Helps/prevent fiber congestion
- Controls force and bend radius



High density patch panels can be tricky to maneuver around when it is fully populated with rigid 90 boots, and the boots can interfere with a technician's access to the panel. SENKO's Flex-Angle boot allows bending in any direction and freedom of movement around other connectors. Also, removing a jumper is made easy; simply straighten out the boot and remove it without worrying about it affecting other connectors in the panel.

Flex-Angle Boot reduces boot protrusion from panel

- LC Conventional Boot
- LC MINI Boot
- LC w/Flex-Angle Boot
- LC w/90 Degree Boot
- LC w/50 Degree Boot
- LC +MINI Boot+



LC FLEX ANGLE BOOT 2mm Boot & 3mm Boot

LC UNIBODY



LC SWITCHABLE




MPO FLEX ANGLE BOOT



3mm Boot



SC FLEX ANGLE BOOT 2mm Boot & 3mm Boot




Senko's new 2.0mm and 3.0mm boot addition for the Premium and Standard SC connectors.

LC FIXED ANGLE BOOT

LC RIGHT ANGLE CLIP

Protected right angle bend

The Right Angle Clip is made to be flexible, yet strong enough to hold the LC 2mm Mini Boot at a right angle without issue. As an added benefit the boot clip can be utilized with connectors already deployed to improve cable management.




LC MINI Boot, LC Mini Boot + Right Angle Clip Open, LC Mini Boot + Right Angle Clip Closed

- G-657-A1 fiber typical loss change under 0.10
- G-657-A2 Fiber typical loss change under 0.02
- Not suggested to use for D-652D fiber

LC 90° ANGLE BOOT



LC 50° ANGLE BOOT



- Provides a fixed angle positioning of 50° for better cable management
- Made of RoHS material and UL94-V0 rated type

FC, ST, DIN, D4 FLEX ANGLE BOOT 3mm Boot

FC



ST



DIN



D4



SENKO's Flex-Angle Boot controls the force and bend radius with little to no increase in insertion loss

(tested to GR326 requirements Section 4.4.3.5, Transmission with Applied Tensile Load).