

# **SMART CLEANER** CS-LC

End face cleaner for CS<sup>®</sup> and LC connectors







**NETWORK EQUIPMENT** 





FIELD INSTALLATIONS ENGINEERING & RESEARCH LABS

### **FEATURES:**

- Cleans 750 end faces
- Cleans both LC and CS<sup>®</sup> connectors in adapters and unmated assemblies.
- Key features of cleaning tip open most internal shutter LC adapters
- RoHS and REACH compliant with no shelf life or restrictions on storage or shipments
- Works for UPC and APC polished end faces.
- Using the replacement refill cartridges for reducing cost per clean
- Refills are sold 3 to a box

**DIMENSIONS:** 

Length: 25.0 cm (9.8 in) Width: 3.0 com (1.2 in)

Height: 4.0 cm (2.0 in)

Weigth: 57 g (2 oz)

Cleaner locks up at end of life to alert operator





Key enables cleaning for both

LC and CS connectors



Dual spines for high stability while cleaning



Duplex connector compatibility



Key

Cleaner: SCK-SS-CS Refill: SCK-SS-CS-R

# **Cleaning for LC connectors**

Adapter LC End Face Cleaning

Unmated LC End Face Cleaning





1. Place the white end cap into the handle.

2. Insert the cleaner into the adapter port and push forward 1X to clean the end face.



1. Open the lid on the white end cap.

2. Insert into the LC connector and push cleaner forward 1x to clean the end face.

### **Cleaning for CS duplex connectors**

Adapter CS Duplex End Face Cleaning



1. Place the white end cap into the handle.

2. Turn the key 90° and insert into the port and push 1X to clean the end face.

3. Turn the key 180° and insert into the port and push 1X to clean the end face

Unmated CS Duplex End Face Cleaning







1. Open the lid on the white end cap.

2. Insert into the CS duplex connector and push cleaner forward 1x to clean the end face.

3. Turn the key 180° then insert into the CS duplex connector and push cleaner forward 1x to clean the end face.

## **Refill replacement:**



- 1. Rotate the orange handle to align the two arrows to go into "Lock Mode".
- 2. Hold the orange handle stationary and pull back on the gray cleaning cartridge
- 3. Place the replacement cartridge into the orange handle. Make sure to align the gray bump into the slots of the white mounting ears in the handle.

### AMERICAS

JS EAST 1.888.32.SENKO |Sales-Americas@senko.com JS WEST 1.858.623.3300 TEXAS 1.972.661.9080

BRAZIL

3RAZIL +55.21.3736.7065 | Sales-Brazil@senko.com

AUSTRALIA & PACIFIC REGION Australia +61.0.3.9755.7922 | Sales-Asia-Pacific@senko.com

#### JAPAN TOKYO +81.0.3.5825.0911 | Sales-Japan@senko.cc

ASIA HONG KONG +852.2121.0516 | Sales-Asia@senko.com SHANGHAI +86.21.5830.4513 SHEZHEN +86.755.25<u>33</u>.4893



#### EUROF

UK +44(0)1256 700880 | Sales-uk@senko.com POLAND +44(0) 7796444488 SPAIN & PORTUGAL +34 678042829 | Sales-Iberia@senko.com GERMANY +49(0)15117683072 | Sales-Germany@senko.com ITALY +39 338 8919089 | Sales-Italy@senko.com FRANCE +44 7939364565 | Salesfrance@senko.com OTHER +44(0) 1256 700880 | Sales-Europe@senko.com