

SENKO NEOCLEAN F 1.25MM

Fiber Optic Connector Click Cleaner

Tool Part Number:
SCK-SS-F125



Hyper Scale



Fiber To The Home



Fiber To The Antenna



Network Installation

FEATURES:

- 1000+ cleanings per tool.
- Cleans LC, MU and ferrule stub LC based transceiver ports including SFP+, QSFP-DD, and OSFP.
- Self aligning, spring controlled cleaning tip for effective and consistent cleaning performance.
- Clear housing for easy viewing of the remaining cleaning strand on the pay off spool.
- REACH and RoHS compliant.

DIMENSIONS

(without end cap)

Length: 163mm (6.4") Width: 15mm (0.6")

Height: 22mm (0.9") Weight: 20g (0.04lbs)



Blue color coded cleaning barrel.



Square barrel for high stability in adapter ports.



Remaining cleaning strand

End cap holding feature in housing when cleaning in adapter end faces.

Precision molded cleaning tip and barrel made with *anti static material*.



Cleaning In Adapter LC/UPC



Cleaning Unmated LC/UPC



HOW TO CLEAN LC/UPC AND MULTIMODE LC END FACES

UNMATED LC/UPC



- 1 Place clear end cap on blue cleaning barrel and open the cover.



- 2 Insert ferrule into port of end cap.
- 3 Push the housing forward to engage.

IN ADAPTER LC/UPC



- 1 Place clear end cap into the housing.
- 2 Insert the blue cleaning barrel into adapter port.



- 3 Push the housing forward to engage.



ATTENTION

THE NEOCLEAN F CLEANER MUST BE POSITIONED **FLAT** WHEN CLEANING ANGLED POLISHED (APC) END FACES.



Aligning for Unmated LC/APC



Aligning for In Adapter LC/APC

HOW TO CLEAN LC/APC END FACES

UNMATED LC/APC



- 1 Place clear end cap on blue cleaning barrel and open the cover.



- 2 Insert ferrule into port of end cap.
The NEOCLEAN F housing need to be aligned to the latch of the LC connector.
- 3 Push the housing forward to engage.

IN ADAPTER LC/APC



- 1 Place clear end cap into the housing.
- 2 Insert the blue cleaning barrel into adapter port.
The NEOCLEAN F housing need to be aligned to the latch of the LC connector.



- 3 Push the housing forward to engage.

For more information or questions, please contact your local SENKO sales representative or email us at sales@senko.com